


PACKAGE CONTENTS

- A. Chimenea
- B. Cap
- C. Stand
- D. Metal Grate



Use your wood-burning Chimenea year-round to bring an inviting ambiance, warm crackling flames, and a delightful wood burning aroma to your backyard. This long-lasting and durable Chimenea will bring enjoyment for years to come.

CARE AND MAINTENANCE

- Always use intended stand. This prevents the porous clay from retaining moisture. Your Chimenea will last longer if it is kept above ground and allowed to breathe.
- Use a 2-3" barrier of sand or peat gravel in the base of the Chimenea. Do not build a fire directly on the clay.
- Cure your Chimenea by building two or three small fires. Allow the clay to cool between firings, for at least 4-6 hours. Once cured, you can build larger fires. Use newspaper to start the fire instead of starter fluid. Do not use charcoal or artificial logs (unless designed for Chimenea use).
- Keep water out of your Chimenea by using the included cap. Shelter your Chimenea in rain or freezing weather (particularly when temperatures drop below 15° F). If water gets inside, replace the sand and allow the Chimenea to dry.
- Clean your Chimenea with water and mild detergent, making sure that it is thoroughly dry before use.
- · Apply a non-flammable water-based sealer annually.

CAUTIONS

- Only intended for outdoor use. Keep away from overhanging roofs, trees, umbrella and other combustible materials.
- Never place Chimenea directly on a patio or deck and always use the intended stand with a 4 feet clearance.
- Never touch the outside of the Chimenea and supervise children when the Chimenea is in use.
- The Chimenea must always be dry before use.
- Extinguish fire before you leaving unattended, however do not use water to extinguish it.
- Use caution when moving your Chimenea. Lift it completely and set down
- carefully and slowly.
- If this care and safety information is not followed, a fire or explosion may result causing property damage, injury or loss of life.

